

AVIOR DC, AVIUM DC

Mennyezeti mélysugárzó
Downlight

SZERELÉSI ÚTMUTATÓ

A lámpatest telepítését és karbantartását csak képzett szakember végezheti! Kérjük, vegye figyelembe a LED fényforrás élettartamára vonatkozó előírásokat! Sérült üveget azonnal ki kell cserélni! A garancia azonnal érvényét veszti, ha a vevő a lámpatesten a gyártó előzetes engedélye nélkül bármilyen módosítást végez! Szakszerűtlen felszerelésből vagy extrém üzemeltetési körülményekből származó meghibásodás esetén a garancia érvényét veszti! A szerelési útmutatót kérjük, őrizze meg!

MAXIMÁLIS KÖRNYEZETI HŐMÉRSÉKLET 35 °C



INSTALLATION INSTRUCTION

The luminaire may only be installed and maintained by qualified technicians! Please pay attention to LED light-source lifetime! The damaged or broken glass must be replaced immediately! Any modifications of the luminaire structure without supplier's permission can end product guarantee! In case of any failure caused by unprofessional installation or operating under extreme conditions the product may end! Please retain these instructions for later reference!

MAXIMUM AMBIENT TEMPERATURE 35 °C



1 **1a** KIVÁGÁS
CUT-OUT
AVIOR - Ø165
AVIUM - Ø195

1b

2

2a

2b

DALI

3

4

2 x

5

AVIUM

300889	300896	300904	300912	300923	300932	300937
300890	300898	300905	300915	300924	300933	300938
300892	300899	300907	300916	300927	300934	300939
300893	300901	300908	300919	300928	300935	300940
300895	300902	300911	300920	300931	300936	300941
						300942

AVIOR

300943	300950	300958	300966	300977	300986	300991
300944	300952	300959	300969	300978	300987	300992
300946	300953	300961	300970	300981	300988	300993
300947	300955	300962	300973	300982	300989	300994
300949	300956	300965	300974	300985	300990	300995
						300996

